



Use airlock to seal off Primary bedroom & Office so that only 1 air scrubber is needed instead of 2

Right Apt.

Left Apt.

↓  
N  
Left Apt