



*interior*

Plywood boarding must be sized to fit existing opening such that boarding sits within existing wood window trim casing. Boarding should properly cover entirety of opening and must be installed such that water is not able to penetrate opening.

